



LITHOS KIT

DISTANCES




LITHOS KIT

CONNECTION DIAGRAMS



LITHOS KIT


CONNECTION DIAGRAMS



LITHOS KIT

CONNECTION DIAGRAMS

ONE call installation with LYNEA BASIC receivers YVL301 (YVCL301) and MASTER/SLAVE function





LITHOS KIT

CONNECTION DIAGRAMS

TWO calls installation:

- Two OPHERA in the call 1 (additional power supply for the second receiver, SW2 in LOCAL position)
- MASTER/SLAVE function between the two LYNEA in the call 2 (SW8)

